

ASUS Xonar Essence One MCU F/W Update


【IMPORTANT】：

When updating firmware , please do not switch off power .


And please plug in to USB 2.0 port.

ASUS Xonar Essence One firmware update procedure :

- (1) Ensure Xonar Essence One is (Power-Off) , press front panel' s " UPSAMPLING" 與 " MUTE" together and then press " POWER" button.




- (2) The front panel COA/TOS/USB LED light will flash 3 times, when all LED becomes red, let go of pressing (UPSAMPLING 、 MUTE 、 POWER). The machine is now ready for firmware update .




ASUS Xonar Essence One MCU F/W Update

- (3) Execute (EOne_127.exe ; 127 is the firmware's serial number) , which you can see at the top of the window.




- (4) Select "Connect" .




ASUS Xonar Essence One MCU F/W Update

(5) Wait for 6~9sec, it will connect to Xonar Essence One




ASUS Xonar Essence One MCU F/W Update

(6) Select "Update" to update firmware




(7) Below is the loading status



ASUS Xonar Essence One MCU F/W Update

(8) Once the firmware has been updated successfully, it will display “PASS”



(9) Press ” POWER” and switch off Xonar Essence One ◦ Now the Xonar Essence One has been updated successfully

ASUS Xonar Essence One MCU F/W Update

(10) Restart Xonar Essence One's power source and check if the updated version is correct.

