

*Eee PC*

**Windows® XP Edition**

**Quick Use Guide**

**Eee PC 8G**

**Eee PC 4G(701)**


**Eee PC 4G(Surf)**




# Powering on your Eee PC

These are only quick instructions for using your Eee PC. Read the full manual for detailed information.


## 1. Install the battery pack



## 2. Connect the AC power adapter



## 3. Turn ON the Eee PC



When you open the display panel, do not force it down to the table or else the hinges may break! Never lift the Eee PC by the display panel!



Remember to fully charge the battery before first use and whenever it is depleted to prolong battery life.

## Status Indicators

Status indicators represent various hardware/software conditions.

-  Power Indicator
-  Battery Charge Indicator
-  Solid State disk (SSD) Indicator
-  Wireless Indicator

# Powering off your Eee PC

Do the following instructions to turn down your Eee PC.

1. Click the **start** button on the bottom left corner of the desktop to display the start menu.
2. Select **Turn Off Computer** from the list.



3. Select **Turn Off** to power off your Eee PC.



# Launching for the First Time

For the first time you start your Eee PC, the Windows wizard will launch automatically and lead you through setting up your preferences and some basic information. Follow the wizard instructions to finish the initialization.

## Configuring a network connection

### Wireless Network Connection


1. Double-click the crossed wireless network icon  on the OS taskbar.



If the wireless connection icon does not show on the taskbar. Activate the wireless LAN function by pressing  +  (<Fn> + <F2>) before configuring a wireless network connection.




2. Select the wireless access point you want to connect to from the list and click **Connect** to build the connection.




If you cannot find the desired access point, click **Refresh network list** in the left pane and search in the list again.

3. When connecting, you may have to enter a password.



4. After a connection has been established, the connection is shown on the list.



5. You can see the wireless network icon on the OS taskbar.



The wireless connection icon disappears when you press Fn +




(<Fn> + <F2>) to disable the WLAN function.

# Local Area Network

If you want to obtain network access, connect the network cable, with RJ-45 connectors on each end, to the network port on the Eee PC and the other end to a hub or switch. The illustration below is the example of your Eee PC connected to a network hub or switch for use with the built-in Ethernet controller. Connect to network before enjoying all the network services and functions in Eee PC.

## Using a dynamic IP:

1. Double-click the network icon with a yellow warning triangle  on the OS taskbar.
2. Right-click **Local Area Connection** and select **Properties**.



3. Highlight **Internet Protocol(TCP/IP)** and click **Properties**.




4. Toggle the first option **Obtain an IP address automatically** and click **OK** to finish the configuration.



### Using a static IP:

1. Repeat the step 1~3 of Using a dynamic IP to start the static IP network configuration.
2. Toggle the second option **Use the following IP address**.



3. Enter the IP address, Subnet mask and Gateway from your service provider.
4. There is no need to enter the DNS address unless you want to override the server provided DNS server address. If so, enter the preferred DNS Server address, alternative address.
5. Click the **OK** button on the bottom to build the network connection.



Contact your service provider if you have problem connecting to the internet.

---