

Self-upgrade guide to Windows® 7 for your Eee PC™ with Windows® XP

Prior to upgrading to Windows® 7, please download the following:

- BIOS (v.1004)
- Chipset Intel 945 (v 9.1.1.1016)
- VGA Intel (v8.15.10.1867)
- Touchpad (Synaptics v13.2.6.1 / Elantech v7.0.5.7)
- Bluetooth (v6.1.7100)
- KB Filter (v1.0.0.3)
- Audio (v 6.0.1.5948)
- LAN (v1.0.0.18)
- Wireless (v8.0.0.238)
- HotkeyService (v1.11)
- Super Hybrid Engine (SHE) (v2.09)
- ASUS Update (v 1.03.04)

Windows® 7 Self-Upgrade Steps

*Please note:

(1) We recommend you follow the step-by-step upgrade instructions as shown in the SOP file. Failure to do so may result in errors during the upgrade process.

(2) For any assistance during the installation process, contact ASUS Support at <http://support.asus.com/contact/contact.aspx?SLanguage=en-us>

1. Under Windows® XP in your Eee PC™, upgrade BIOS via the ASUS Update (for Windows® XP).
2. Install Windows® 7 operating system from the DVD.
*Please note: Ensure that it is in the same language as your current Windows® XP operating system.
3. Install required drivers, utilities, and applications in the following order:
 - 1) Chipset Intel 945: Run "Setup.exe"
 - 2) VGA Intel: Run "Setup.exe"
 - 3) Hotkey Service: Run "HotkeyService_1.11.exe"
 - 4) Touchpad: Run "Setup.exe"
 - 5) Bluetooth: Run "Setup.exe"
 - 6) KB Filter: Run "PNPINST.exe"
 - 7) Audio: Run "Setup.exe"
 - 8) LAN: Run "Setup.exe" in the "Atheros" folder
 - 9) Wireless: Run "Setup.exe" in the "Install_CD" folder
 - 10) Super Hybrid Engine: Run "SuperHybridEngine_2.09.exe"
 - 11) ASUS Update: Run "AsusSetup.exe"