



E3701

NAVIGATION MAP


FOR R300/R600/R700



Using the Navigation Map

R300

1. Insert the microSD card into the microSD card slot (1) on top of the device when the device is either turned off or in sleep mode.
2. Switch the power **ON** (2) to turn on the device, or press the sleep mode button (3) to wake up the device.
3. From the main screen, tap **Navigation** and follow the screen instructions.




Note

If you turn on or wake up the device without inserting the microSD card into the microSD card slot, when tap **Navigation** from the main screen, a warning message appears: "**Operation failed! Insert the SD card or remove USB and try again**". You may insert the microSD card and try again.

Using the Navigation Map


R600

1. Insert the microSD card into the adapter.
2. Insert the adapter with the microSD card into the SD card slot (1) on the right side of the device when the device is switched off or when the device is in sleep mode.
3. Switch the power ON (2) to turn on the device, or press the sleep mode button (3) to wake up the device.
4. From the main screen, tap **Navigation** and follow the screen instructions.



Note

If you turn on or wake up the device without inserting the microSD card into the card slot, when tap **Navigation** from the main menu, a "Map initialisation error" message appears: **couldn't find any map files!**. Follow step 1 to insert the microSD card into the card slot, tap **OK** from the error message to go back to the main menu, and then tap **Navigation**.




Using the Navigation Map

R700

1. Insert the microSD card into the microSD card slot (1) on the left side of the device.

Note


You can insert the microSD card into the device when it is in sleep mode or is switched off.



Note

If you insert the microSD card when the device is in sleep mode, press the Sleep Mode Button (2) and wait for a few seconds until the main menu appears, then tap **Navigation** to proceed.

If you insert the microSD card when the device is switched off, switch the power **ON** (3) to turn on the device, then tap **Navigation** after the main menu appears.



2. From the main menu, tap **Navigation** to navigate using the map in the microSD card.