

## VGA/Monitor Qualified Vendor List of HDAV 1.3

No.	VGA Card Model	VBIOS Version
1	ASUS EAH2400PRO/HTP/256M	(BIOS: V94C3.10.53.00.00.AS01)
2	ASUS EAH2400XT/HTP/256M	(BIOS: V94C1.10.56.0.5.AS01)
3	ASUS EAH2600PRO/HTDP/256M	(BIOS: V9589.10.56.0.5.AS05)
4	ASUS EAH2600XT D4/HTDI/256M	(BIOS: V9588.10.52.0.0.AS01)
5	ASUS EAH2600XT/HTDI/256M	(BIOS: V9588.10.56.0.5.AS01)
6	ASUS EAH2900XT/512MX16	(BIOS: V9400.10.47.0.0.AS01)
7	ASUS EAH3450/HTP/256M	(BIOS: V95C5.10.75.0.2.AS01)
8	ASUS EAH3650 Silent MG /HTDP/512M	(BIOS: V9598.10.74.0.2.AS03)
9	ASUS EAH3650 Silent/HTDI/1GB	(BIOS:V9598.10.85.0.1.AS01)
10	ASUS EAH3650 TOP /HTDI/256M	(BIOS: V9598.10.74.0.2.AS03)
11	ASUS EAH3850 SMART OC /HTDI/1GB	(BIOS: V9505.10.80.0.1.AS01)
12	ASUS EAH3850 TOP /HTDI/512M	(BIOS: V9505.10.76.0.1.AS01)
13	ASUS EAH3850/HTDI/256M	(BIOS: V9505.1067.0.0.AS01)
14	ASUS EAH3870 TOP /HTDI/512M	(BIOS: V9501.10.78.0.0.AS03)
15	ASUS EAH3870/HTDI/512M	(BIOS: V9501.10.67.0.0.AS01)
16	ASUS EAH3870X2 TOP/3DHTI/1GB	(BIOS: V950F.10.77.0.0.AS23)
17	ASUS EAH3870X2/HTDI/1GB	(BIOS: V950F.10.75.0.2.AS01)
18	ASUS EAH4850/HTDI/512M/A	(BIOS:V9442.11.4.0.0.AS01)
19	ASUS EAH4870/HTDI/512M/A	(BIOS:V9440.11.3.0.1.AS01)
20	ASUS EAH4870X2/HTDI/2GB/A	(BIOS:V9441.11.07.0.0.AS01)
21	ASUS EAX1300HM512/TD/256M	(BIOS:V7187.9.12.8.2.AS13)
22	ASUS EAX1550 Silent/TD/512M/A	(BIOS:V715F.9.13.1.29.AS13)
23	ASUS EAX1550/TD/256M/A	(BIOS:V7143.9.13.1.22.AS01)
24	ASUS EAX1600PRO TOP/HTD/128M	(BIOS: 71C3.9.13.1.20)
25	ASUS EAX1600PRO/256MB V.1.01	(BIOS: 71C2.9.12.6.2)
26	ASUS EAX1600PRO//256M	(BIOS: 71C2.9.12.8.2)
27	ASUS EAX1600XT Silent/256MB V.1.00	(BIOS: 71C0.9.12.4.2)
28	ASUS EAX1650PROGE/HTD256MX16	(BIOS: 71C1.9.13.1.18.AS03)
29	ASUS EAX1650XT/256MB V.1.00	(BIOS:009.013.001.000)
30	ASUS EAX1800XT/2DHTV/512MB	(BIOS: V7100.9.12.4.2.AS01)

31	ASUS EAX1900CrossFire	(BIOS: 7249.9.12.5.2AS05)
32	ASUS EAX1900XTX	(BIOS: V009.012.005.002)
33	ASUS EAX1950PRO/HTDP/256M	(BIOS: V009.013.001.009)
34	ASUS EN6200LE TC512/TD/256M	(BIOS: V5.44.02.67.AS13)
35	ASUS EN7200GS/HTD/256M	(BIOS: V5.72.22.75.AS05)
36	ASUS EN7300GS/HTD/256M	(BIOS: V5.72.22.34.AS05)
37	ASUS EN7300LE/HTD/128M	(BIOS: V5.72.22.43.AS09)
38	ASUS EN7600GS Silent 256MB	(BIOS: V5.73.22.19.AS07)
39	ASUS EN7600GS TOP Silent 512MB	(BIOS: V5.73.22.20.AS03)
40	ASUS EN7600GT Silent/256M	(BIOS: V5.73.22.15.01)
41	ASUS EN7600GT/256MB	(BIOS: V5.73.22.15.02)
42	ASUS EN7600GT/HTDI/256M	(BIOS: V5.73.22.19.AS15)
43	ASUS EN7800GT /256MB	(BIOS:V5.70.02.13.AS01)
44	ASUS EN7800GTX /256MB	(BIOS:V5.70.02.11.AS01)
45	ASUS EN7900GS/256MX16	(BIOS: V5.71.22.41.AS01)
46	ASUS EN7900GT TOP /256MX16	(BIOS: V5.71.22.12.02)
47	ASUS EN7900GTX /512MX16	(BIOS: V5.71.22.12.01)
48	ASUS EN7950GX2/2PHT/1G	(BIOS: V5.71.22.41.AS01)
49	ASUS EN8400GS Silent/HTP/256M	(BIOS:V62.98.12.00.AS05)
50	ASUS EN8400GSSilent/HTP/512M	(BIOS:V62.98.12.00.AS13)
51	ASUS EN8500GT Silent/HTD/256M	(BIOS:V60.86.26.00.AS01)
52	ASUS EN8500GT Silent/HTD/512M	(BIOS:V60.86.34.00.AS07)
53	ASUS EN8500GT TOP/HTP/256M	(BIOS:V60.86.39.00.AS21)
54	ASUS EN8500GT/HTD/256M	(BIOS:V60.86.39.00.AS05)
55	ASUS EN8600GT GENT2/256M	(BIOS:V60.84.5D.00.00)
56	ASUS EN8600GT MG/HTP/512M	(BIOS:V60.84.6B.00.AS01)
57	ASUS EN8600GT Silent/HTDP/256M/A	(BIOS:V60.84.41.00.AS41)
58	ASUS EN8600GT/2DHT/256M/A	(BIOS:V60.84.31.00)
59	ASUS EN8600GT/HTDP/512M/A	(BIOS:V60.84.41.00.AS07)
60	ASUS EN8600GTS Silent/HTDP/256M/A	(BIOS:V60.84.41.00.AS09)
61	ASUS EN8800GS/HTDP/384M	(BIOS: 62.92.29.00.AS21)
62	ASUS EN8800GT TOP HTDP/512M	(BIOS: 62.92.1A.00.AS15)
63	ASUS EN8800GT/G/HTDP/512M	(BIOS: 60.92.16.00.AS01)

64	ASUS EN8800GT/HTDP/256M	(BIOS: 62.92.29.00.AS03)
65	ASUS EN8800GTS 320M	(BIOS:60.80.0D.00.01.AS01)
66	ASUS EN8800GTS 640M	(BIOS: V60.80.13.00.AS05)
67	ASUS EN8800GTS TOP 5120MX16	(BIOS: V62.92.3A.00.AS03)
68	ASUS EN8800GTX 768MX16	(BIOS: V60.80.06.00.02)
69	ASUS EN8800Ultra/HTDP/768M	(BIOS: 60.80.18.00.AS05)
70	ASUS EN9600GSO MG HTDP/512M	(BIOS: V62.92.3B.00.AS09)
71	ASUS EN9600GT MT/HTDI/512M	(BIOS: V62.94.11.00.AS49)
72	ASUS EN9600GT Silent/HTDI/512M	(BIOS: V62.94.11.00.AS15)
73	ASUS EN9600GT/HTDI/512M	(BIOS: V62.94.11.00.AS01)
74	ASUS EN9600GT/HTDP/512M	(BIOS: V62.94.0D.00.AS01)
75	ASUS EN9800GTX TOP/HTDP/512M	(BIOS: V62.92.3B.00.AS03)
76	ASUS EN9800GTX+/HTDI/512M/A	(BIOS: V62.92.5D.00.AS01)
77	ASUS EN9800GX2 TOP/HTDP/1G	(BIOS: V62.92.39.00.AS09)
78	ASUS ENG TX260/HTDI/896M	(BIOS: V62.00.0E.00.AS11)
79	ASUS ENG TX280/HTDI/1G	(BIOS: V62.00.0E.00.AS09)
80	ATI FireMV2200	(BIOS: V113.A25915.100)
81	ATI-X1950XTX/512MX16	((BIOS: V7240.9.12.5.2.AS01)
82	Elsa ATI Fire GL V3100	(BIOS: V113.A33429.100)
83	Elsa ATI Fire GL V3300	(BIOS: V113.A77601.105)
84	GAINWARD GeForce 9600GT/512MB	(BIOS:62.94.3c.00.00)
85	Gecube RADEON X1300PRO	(BIOS: V133.A671B1.102)
86	Gigabyte GV-NX84G256HE/256M	(BIOS:v60.86.50.00.00)
87	Gigabyte GV-NX86T256H-ZL	(BIOS:v60.84.5E.00.00)
88	Gigabyte GV-R485-512H-B	(BIOS:V011.004.000.000.029193)
89	Gigabyte GV-RX19X512VB-RH	(BIOS:113A52021-104)
90	Gigabyte GV-RX24P256H	(BIOS:V010.052.000.001)
91	Leadtek Quadro FX1400 128M	(BIOS:V5.41.02.43.03)
92	Leadtek Quadro FX540 128M	(BIOS:V5.43.02.64.35)
93	Matrox Millennium P690 Plus LP	(BIOS:V1.4 b05)
94	Matrox Parhelia APVe 128M	(BIOS: V1.3-11)
95	MSI N9600GSO T2D384	(BIOS: V62.92.42.00.09)
96	MSI N9600GT T2D512SP	(BIOS: V62.94.0D.00.02)

97	MSI RX2600PRO/T2D/256M	(BIOS: V010.053.000.003)
98	PowerColor AX3450/256M/DDR2	(BIOS: V010.066.002)
99	Powercolor-X1950PRO/256M	(BIOS:V113-Aa99902-108)

## Fail Item:

No	VGA Card Model	Problem
1	ASUS EAX1050/TD/256M/A	It happens no display problem while getting into DOS mode or you doesn't install the drivers. (The problem only happens to using certain monitor, such as LG245WP-BW)
2	ASUS EAX1300HM512/TD/256M	It may flicker at 1920*1200 resolution.

	Monitor	Problem
1	LG L245WP-BW	There's no display if you doesn't install the audio driver before you watching the HDCP protected movie.