





ASUS[®]

PG348Q


1





2





3






4



4



5



ASUS CONTACT INFORMATION

<ul style="list-style-type: none"> ASUSTeK Computer Inc. Address 15 Li-Te Rd., Peitou, Taipei 11259, Taiwan Telephone +886-2-2894-3447 Fax +886-2-2894-7798 E-mail info@asus.com.tw Website http://www.asus.com.tw/ 	<ul style="list-style-type: none"> ASUS Computer International (America) Address 800 Corporate Way, Fremont, CA 94539, USA Fax +1-510-608-4555 Website http://usa.asus.com/ 	<ul style="list-style-type: none"> ASUS Computer GmbH (Germany and Austria) Address Harkortstr. 21-23, D-40880 Ratingen, Germany Telephone +49-1805-010920 Website http://www.asus.de/ Online Contact http://www.asus.de/sales
<ul style="list-style-type: none"> Technical Support Telephone +86-21-38429911 	<ul style="list-style-type: none"> Technical Support Telephone +1-812-282-2787 (English Only) +1-905-370-2787 (French Only) Online Support http://support.asus.com/ 	<ul style="list-style-type: none"> Technical Support Telephone +49-1805-010923 Support Fax +49-2102-959911 Online Support http://support.asus.com/